


TITAN CLOCKS

Digital Clocks' Operating Manual

①



(Insert four AA batteries first)

②

Time Setting

1. Long-press the “SET” button to enter setting mode.
2. The time format will now start blinking. Press the “UP/DOWN” button to select either the 24-hour or 12-hour time format. Press the “SET” button to move to the next setting.
3. The hour digit(s) will start blinking now. Press the “UP/DOWN” button to set the time hour. Press the “SET” button to move to the next setting.
4. The minute digit(s) will start blinking. Press the “UP/DOWN” button to set the time minute. Press the “SET” button to move to the next setting.
5. The YEAR digit(s) will start blinking now. Press the “UP/DOWN” button to set the time hour. Press the “SET” button to move to the next setting.
6. The month digit(s) will start blinking. Press the “UP/DOWN” button to set the month (1-12). Press the “SET” button to move to the next setting.
7. The date digit(s) will start blinking. Press the “UP/DOWN” button to set the date (1-31). Leave the clock idle for 30 seconds. Clock is ready for use!

Note: The day gets updated automatically once above steps are followed. During the setting mode, if no button is pressed for 30 seconds, the clock will return to normal state. Follow the above steps again, if further adjustments are required.

③

Alarm Setting & Selection

Alarm Setting: Long-press the “ALARM” button to enter into setting mode for Alarm #1

- a) The alarm hour will start blinking now. Press “UP/Down” button to set the desired alarm hour. Press the “ALARM” button to move to the next setting.
- b) The alarm minute will start blinking now. Press “UP/Down” button to set the desired alarm minute. Press the “ALARM” button to move to Alarm #2.
- c) Set the desired hour and minute for Alarm #2 as per same procedure above.

Alarm Selection: short press the “ALARM” button:

- Once to select / opt for Alarm #1
- Twice to select / opt for Alarm #2
- Thrice to select / opt for both Alarm #1 & Alarm #2
- Fourth time to remove / opt out of both alarms

At a time, two alarms can be selected / opted for. If no alarm is required, just follow Alarm Selection process above, to point ‘iv’.

Snooze: Press any of the snooze buttons at the back, to snooze the ongoing alarm by 5 minutes.

Alarm Shut Off: Press any of the buttons (other than Snooze) at the back, to shut off the ongoing alarm.

Temperature

The clock automatically senses the room temperature, and updates the display in every 30 seconds.


Measurement range: -9.9°C to 50°C (If < -9.9°C, Indication: LL.L and if > 50 °C, Indication: HH.H). Accuracy is ±2°C.

Press DOWN button once to switch from Fahrenheit to Celsius (°F/°C).

TITAN CLOCKS

Digital Clocks' Operation Manual

①



(Insert four AA batteries first)

②

Time Setting

1. Long-press the “SET” button to enter setting mode.
2. The time format will now start blinking. Press the “UP/DOWN” button to select either the 24-hour or 12-hour time format. Press the “SET” button to move to the next setting.
3. The hour digit(s) will start blinking now. Press the “UP/DOWN” button to set the time hour. Press the “SET” button to move to the next setting.
4. The minute digit(s) will start blinking. Press the “UP/DOWN” button to set the time minute. Press the “SET” button to move to the next setting.
5. The YEAR digit(s) will start blinking now. Press the “UP/DOWN” button to set the time hour. Press the “SET” button to move to the next setting.
6. The month digit(s) will start blinking. Press the “UP/DOWN” button to set the month (1-12). Press the “SET” button to move to the next setting.
7. The date digit(s) will start blinking. Press the “UP/DOWN” button to set the date (1-31). Leave the clock idle for 30 seconds. Clock is ready for use!

Note: The day gets updated automatically once above steps are followed. During the setting mode, if no button is pressed for 30 seconds, the clock will return to normal state. Follow the above steps again, if further adjustments are required.

③

Alarm Setting & Selection

Alarm Setting: Long-press the “ALARM” button to enter into setting mode for Alarm #1

- a) The alarm hour will start blinking now. Press “UP/Down” button to set the desired alarm hour. Press the “ALARM” button to move to the next setting.
- b) The alarm minute will start blinking now. Press “UP/Down” button to set the desired alarm minute. Press the “ALARM” button to move to Alarm #2.
- c) Set the desired hour and minute for Alarm #2 as per same procedure above.

Alarm Selection: short press the “ALARM” button:

- Once to select / opt for Alarm #1
- Twice to select / opt for Alarm #2
- Thrice to select / opt for both Alarm #1 & Alarm #2
- Fourth time to remove / opt out of both alarms

At a time, two alarms can be selected / opted for. If no alarm is required, just follow Alarm Selection process above, to point ‘iv’.

Snooze: Press any of the snooze buttons at the back, to snooze the ongoing alarm by 5 minutes.

Alarm Shut Off: Press any of the buttons (other than Snooze) at the back, to shut off the ongoing alarm.


Temperature

The clock automatically senses the room temperature, and updates the display in every 30 seconds.


Measurement range: -9.9°C to 50°C (If < -9.9°C, Indication: LL.L and if > 50 °C, Indication: HH.H). Accuracy is ±2°C.

Press DOWN button once to switch from Fahrenheit to Celsius (°F/°C).

1



2



3

4